



UNITED

LABORATORIES

NO ACIDS...NO CAUSTICS...NO EMULSIFIERS!

United 722SF BioSPOR-E provides natural, biological treatment of organic waste and build-up in surgical suction system drains. This reduces back-ups and odors.

- **BIOSPOR-E** goes to work in minutes, breaking down drain waste, sludge and human proteins that cause drain blockage.
- Enzymes work as predigesters to break down human proteins, long-chain fatty acids, biofilm and organic accumulation in the drains.
- Three strains of Facultative Bacillus beneficial bacteria continue to digest wastes within the drains.
- Organic digestion is beneficial in operating room, laboratory, autopsy and pathology drains.

Once established in drains, the **United 722SF BioSPOR-E** will clean and purge the system of organic debris and continue to keep it clean as long as the product is used.

DIRECTIONS FOR USE:

This container is specifically designed for use with one of United's SureFlo Dosing Systems. Shake product before installing into the SureFlo Dosing System. Remove the cap from the container. Do not tamper with the insert that feeds into the container. Place the product container into the gallon housing portion of the SureFlo Dosing System and turn the locking mechanism at the top of the system to the left to lock it into place and automatically connect to the SureFlo feeding tube.

Consult with your United Representative about programming the SureFlo Dosing System to provide the most effective control in your systems. Typically, end of day or night time scheduling works best.

722SF

BIO|SPOR-E

MAINTENANCE TREATMENT SYSTEM FOR OPERATING ROOM, LABORATORY, AUTOPSY AND PATHOLOGY DRAINS

Manufactured and Sold Exclusively by:
UNITED LABORATORIES, INC.
320 37th Avenue • St. Charles, IL 60174
1-800-323-2594 • www.unitedlabsinc.com

BATCH #

NET
CONTENTS

STORAGE AND HANDLING:

Although this product is very low in toxicity, it should be stored in a cool, dry place. Keep out of sunlight. Wash hands thoroughly after using. Do not take internally. Avoid contact with eyes or open wounds. Avoid exposure to extreme temperatures below 35°F (2°C) and above 130°F (54°C), disinfectants, or chlorine compounds such as bleach.

FIRST AID MEASURES:

IF IN EYES: Flush with plenty of water for at least 15 minutes and call a physician or poison control center.

IF ON SKIN: Wash with soap and water. If irritation persists, call a physician or poison control center.

IF INHALED: Remove to fresh air. If symptoms develop, seek medical attention. If not breathing, give artificial respiration.

IF SWALLOWED: Rinse mouth and throat. Give two glasses of water. Never give anything by mouth to an unconscious person. Do not induce vomiting. Call a physician or poison control center.

An SDS for this product is available on United's website. Please read the SDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

KEEP OUT OF REACH OF CHILDREN.



Made in the USA